







• IP fixe 192.168.1.35.
Mot de passe : 12345












• Fixed IP 192.168.1.35.
Password: 12345

• IP fija 192.168.1.35.
Contraseña : 12345




						NFC 15-100
Input	Output	Input	RJ 45	0°C → +45°C		
220 - 240 V~	TBTS 27 V=	50 - 60 Hz	2 x 2,5 mm ²	RJ 45	0°C → +45°C	


- Configuration sur installation
- Configuration as part of installation
- Configuración en la instalación




- Configuration hors installation (autonome)
- Separate (stand-alone) configuration
- Configuración fuera de la instalación (autónoma)



0 766 06/07/09/11





**APPEL INFIRMIÈRE
BUS/SCS**

GUIDE D'INSTALLATION ET D'UTILISATION

www.legrand.com
legrand

i www.legrandoc.com